

FLEXI RAMP



PRODUCT MANUAL

Flexi Ramp is a reusable, durable ramp designed to protect door frames and floors while facilitating the safe transport of heavy materials. This manual provides instructions for setup, operation, safety, maintenance, and troubleshooting. Please read all sections carefully before using the Flexi Ramp.



TABLE OF CONTENTS

TABLE OF CONTENTS.....	2
1. SAFETY INFORMATION.....	3
Important Safety Warnings:.....	3
General Safety Guidelines:.....	3
2. PRODUCT SPECIFICATIONS.....	4
3. SETUP AND INSTALLATION.....	5
1. Preparing the Area:.....	5
2. Positioning the Ramp:.....	5
3. Securing the Ramp:.....	5
4. OPERATING INSTRUCTIONS.....	6
1. Before Use:.....	6
2. Using the Ramp:.....	6
3. After Use:.....	6
5. MAINTENANCE AND CARE.....	7
• Cleaning:.....	7
• Inspection:.....	7
• Storage:.....	7
6. CONTACT AND SUPPORT INFORMATION.....	8
Flexi Ramp Customer Support	
Email: admin@flexiramp.com.au	
Website: flexiramp.com.au	8
Warranty and Return Policy.....	8



1. SAFETY INFORMATION

Important Safety Warnings:

- Only use the Flexi Ramp for its intended purpose: to protect door frames and floors during the transport of heavy objects.
- Do not exceed the weight limit of 250kg.
- Ensure the ramp is stable and secure before use.
- Avoid using the ramp on slippery or uneven surfaces to prevent accidental movement.
- Always wear proper safety gear (e.g. gloves, safety boots) when handling heavy materials on the ramp.
- Ensure the ramp is stable and secure before use. The transition section of the ramp must be sitting flat on a surface.

General Safety Guidelines:

- Inspect the ramp for any visible damage or wear before each use.
- Store the ramp in a safe location when not in use to prevent accidental damage.



2. PRODUCT SPECIFICATIONS

- Dimensions:
 - Height: Adjustable as required
 - Width: 700mm Internal width 600mm
 - Length: 772mm
 - Overall length when fully open 1544mm
- Weight: 15kg
- Material: High-Density Polyethylene (HDPE)
- Weight Capacity: 250kg
- Features: Slip-resistant surface, hi-vis yellow colour for visibility, recyclable material



3. SETUP AND INSTALLATION

1. Preparing the Area:

- Ensure the area around the doorway is clear of obstructions.
- Place the Flexi Ramp on a flat, dry surface to minimise slipping.
- We recommend placing protective material over the door frame for added protection

2. Positioning the Ramp:

- Align the ramp with the door frame or raised surface you wish to protect.
- Adjust the height if needed to ensure a smooth transition over the threshold.

3. Securing the Ramp:

- Flexi Ramp has a slip-resistant surface, but if additional stability is needed, consider using anti-slip mats or securing the ramp in place with a stabilising material.
- Use fixings to secure ramp for a permanent installation during construction stages of building.



4. OPERATING INSTRUCTIONS

1. Before Use:

- Ensure the ramp is properly positioned and stable.
- Verify that the ramp can support the load without tilting or shifting.

2. Using the Ramp:

- Carefully wheel, carry, or slide heavy objects across the ramp.
- Avoid sudden movements or shifts in weight, which could cause the load to become unstable.

3. After Use:

- Inspect the ramp for any visible wear or damage.
- Store the ramp in a dry, cool place away from direct sunlight to maintain its quality and longevity.
- Flexi Ramp has a UV stabiliser which prevents discolouring



5. MAINTENANCE AND CARE

- **Cleaning:**
 - Clean the ramp with a mild detergent and water after each use, especially if it has come into contact with dirt, grease, or other debris.
 - Avoid using harsh chemicals or abrasive tools that may damage the HDPE surface.
- **Inspection:**
 - Regularly inspect the ramp for any signs of wear, such as cracks, warping, or loose material.
 - If any part of the ramp appears damaged, refrain from using it until it has been repaired or replaced.
- **Storage:**
 - For extended life we recommend you store Flexi Ramp indoors in a cool, dry area.



6. CONTACT AND SUPPORT INFORMATION

For additional support, warranty claims, or to report a faulty product, please contact us:

Flexi Ramp Customer Support

Email: admin@flexiramp.com.au

Website: flexiramp.com.au

Warranty and Return Policy

Flexi Ramp products include a 12-month manufacturer warranty for defects in materials and workmanship under correct use conditions. If a defect is found within the warranty period, contact our support team for assistance. In compliance with Australian Consumer Law, faulty products may be eligible for a refund or replacement. Please retain your proof of purchase when making a warranty claim.

LOVE FLEXI RAMP? LEAVE US A REVIEW!

